

1241	Pulsair pump	پمپ هوا
1240	Induction air temperature sensor	سنسور دمای هوا
1225	Idling regulation stepper motor (MMBA)	استپ موتور
1220	Coolant temperature sensor	فشنگی آب
1210	Fuel pump	پمپ بنزین
1203	Interia switch	سوئیچ اینرسی
1135	Ignition coil	کوئل دوپل
1120	Knock sensor	سنسور ضربه
1115	Cylinder reference sensor 1	سنسور مرجع سیلندر ۱
0004	Instrument panel	جلو آمپر

1241	Pulsair pump	پمپ هوا
1240	Induction air temperature sensor	سنسور دمای هوا
1225	Idling regulation stepper motor (MMBA)	استپ موتور
1220	Coolant temperature sensor	فشنگی آب
1210	Fuel pump	پمپ بنزین
1203	Interia switch	سوئیچ اینرسی
1135	Ignition coil	کوئل دوپل
1120	Knock sensor	سنسور ضربه
1115	Cylinder reference sensor 1	سنسور مرجع سیلندر ۱
0004	Instrument panel	جلو آمپر

Tondar 90

List components	کد قطعه
INJECTION COMPUTER	120
PINKING SENSOR 1	146
ATMOSPHERIC PRESSURE SENSOR	147
TDC SENSOR	149
INJECTOR 1	193
INJECTOR 2	194
INJECTOR 3	195
THROTTLE POTENTIOMETER	222
POWER ASSISTED STEERING PRESSURE SWITCH	224
DIAGNOSTIC SOCKET	225
WATER INJECTION TEMPERATURE SENSOR	244
INSTRUMENT PANEL	247
VEHICLE SPEED SENSOR	250
INJECTION AIR TEMPERATURE SENSOR	272
FAN SPEED 2 RELAY	336
PETROL VAPOUR ABSORBER	371
ENGINE AND RELAY FUSE BOX	597
STEPPER MOTOR	649
COMMAND RELAY BLOCK 2	784
FUEL PUMP AND SENDER UNIT	833

UPSTREAM OXYGEN SENSOR	887
PASSENGER COMPARTMENT FUSE BOX	1016
INJECTION RELAY	1047
CYLINDER 1 PENCIL COIL	1077
CYLINDER 2 PENCIL COIL	1078
CYLINDER 3 PENCIL COIL	1079
CYLINDER 4 PENCIL COIL 4	1080
COOLANT GAS PRESSURE SENSOR	1202
EVAPORATOR SAFETY MODULE	1840
ENGINE/PASSENGER COMPARTMENT (SINGLE UNIT) CONNECTION	R212

WWW.CNG20.COM